

Network ports used by GeoVision

WebCam		Http = 80 FTP = 21 Command = 4550 Data = 5550 Audio = 6550 Remote Control = 3389 SSL = 443 Mobile = 8866 Mobile RPB = 5511 3G RTSP / TCP = 8554 3G RTP /RTCP UPP = 17300-17380
RemotePlayBack		RPBSvr = 5066
RemoteView		TCPSvr = 3550
VSM		Server = 5610
TwinServer		Server = 9650 Multicast = 19650
TwinDVR		Http = 80 FTP = 21 Command = 4550 Data = 5550 Remote Control = 3389
IP Multicast		DMMCast = 3650
Authentication Server		Server = 3663
SMS		Server = 6886
CenterV2	At DVR subscriber site	Command = 5548 Connection Port = 5545 Data = 5549 Audio = 5546
	At Center V2 site	Center = 5547 Connection = 5551
Dispatch Server		Server = 21112
GeoCenter		Server = 20001
DMIP		FTP = 21
DDNS		Server = 80 and 81
Control Center	At DVR host site	Command Port = 3388 Data Port = 5611 Log Port = 5552
	At Control Center site	Command Port = 3388
TCP Server		Server = 3550
UPnP		TCP/IP = 5200
Wiegand Capture Server		Server = 5612